

Installation Guide: Z-Clips

Tools & Materials Needed:

- **Z-clips (Included)**
- **Level**
- **Drill**
- **Screws (Included)**
- **Stud Finder**
- **Marking pencil**

Step 1: Determine the location on the wall where the panel will be mounted. The ideal location will be in front of a wall stud. Use a stud finder to locate the stud nearest the hanging/mounting position on the wall.

Step 2: Secure the z-clips on the wall by drilling in one of the screws. The clips should be tight enough to stay in place, but loose enough to move with your hand for adjusting.

Step 3: Check to make sure that the secured z-clips are level using a leveling tool. Once level, mark the location on the wall with a pencil through the second open hole.

Step 4: Install the remaining screws to fully secure z-clips to the wall (fully tighten the first screw).

Step 5: Mount the acoustic panel on the wall, and verify that the item sits flush and is secure with the mounted z-clips.