

# Installation Guide: SilentPoly™ Dual-Tone Panels

## Wall Mounting Polyester Panels:

- 1.) Find a spot on the wall where each panel will be placed, keep all panels spaced out accordingly and level with one another.
  - 2.) Using a pencil, score a small mark at the top of each panel.
  - 3.) Place a Velcro dot in each corner of the panel, as well as in the center, with the hook side penetrating the soft white core of the panel.
  - 4.) Once the Velcro dots are in place on the panel, press the panel firmly on the wall, aligned with the pencil score mark - press firmly on the corners and in the center of the panel so that the adhesive side of the Velcro dot adheres to the wall.
- (To make adjustments after hanging, peel the panel off of the Velcro slowly and adjust)**

## \*For concrete walls:

- Use glues or adhesives to adhere the panel to the wall.
- Press firmly for up to 60 seconds to be sure the panel has a solid hold.

